

Washing Instruction for Clear Shield treated glass.



Clean-All

Water-based wash concentrate for routine maintenance of the **Clear Shield** glass and untreated glass, as well as other surfaces. Removes mud, salt, inorganic materials, etc.

We recommend you wash whenever necessary, and at least once per week. Start with flushing of fresh water and use about 5 minutes with a bucket and a microfiber pad.

1. Flush with fresh running water, to remove the most. (Do not high pressure)
2. Mix in **clean-all** relative: **1-20**
Stronger mix when needed.
3. Use the wash brush as shown in the picture.
4. If the glass is very dirty, repeat step 3
5. Flush with fresh water.
6. DO NOT let Clean-All dry out on the glass, if this should happen - apply water for re-activation.



You need:

- **Wash concentrate** (Clean-All : art.nr: **3ACA03D/3ACA05/3ACA25**)
- **Bucket** (14 Liter art. nr: 910038)
- **Long pool** (2x2 mtr. art.nr: 910090)
- **Doodlebug –swivel** (art.nr: 910043)
- **Micropad** (art.nr: 910043)

Pack sizes: 0,5 ltr/5 ltr/25 ltr/190 ltr.

Safety and health:

Although Clean All, is a mild product, which also freshen up **Clear Shield** treatment: Avoid contact with eyes and prolonged contact with skin.

Use rubber gloves or disposable nitrile gloves in addition to the eye protection.

Classified as "not dangerous" Feel free to read the HSE data sheet, if necessary.

For additional information: